

Speed Dome Baseline V2.640.0000000.5.R

Version User Manual

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Copyright

© 2017 ZHEJIANG DAHUA VISION TECHNOLOGY CO.,LTD.. All rights reserved.

Any or full contents of the user's manual cannot be copied, transmitted, distributed or stored, partially or wholly, by any means, without the prior written notice of ZHEJIANG DAHUA VISION TECHNOLOGY CO.,LTD. (hereinafter "Dahua").

Dahua or the third party may reserve the right of the software described in this user's manual. Without the prior written approval of the corresponding party, any person cannot copy, distribute, amend, abstract, reverse compile, disassemble, decode, reverse engineering, rent, transfer or sub-license the software.

Trademark



HDMI logo, HDMI and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC. This product has been authorized by HDMI Licensing LLC to use HDMI technology.

VGA is the trademark of IBM.

Windows logo and Windows are trademarks or registered trademarks of Microsoft.

Other trademarks and company names mentioned are the properties of their respective owners.

About this Document

This document is for reference only. Please refer to the actual product for more details.

This document serves as a reference for multiple types of products, whose specific operations won't be enumerated. Please operate according to actual products.

The user shall undertake any losses resulting from violation of guidance in the document.

In case that PDF document cannot be opened, please upgrade the reading tool to the latest version or use other mainstream reading tools.

This company reserves rights to revise any information in the document anytime; and the revised contents will be added to the new version without prior announcement. Some functions of the products may be slightly different before and after revision.

The document may include technically inaccurate contents, inconsistencies with product functions and operations, or misprint. Final explanations of the company shall prevail.

Contents

| Before Start | | | | | | |
|--------------|-----------------------------------|---|--|--|--|--|
| | Version Info 1 | | | | | |
| 1 | Version Basic Info | 1 | | | | |
| 2 | Newly Added or Enhanced Functions | 2 | | | | |
| 3 | Fix Bugs | 3 | | | | |
| | Version Matched Info | 3 | | | | |

Version Info

1 Version Basic Info

| Product Name | V2.640.0000000.0.R.180502 |
|----------------|--|
| | DH_SD-Yin-Demeter_Internal_NP_Stream3_Intelligent_V2.640.0000000.5.R.1 |
| | 80921.zip |
| | DH_SD-Yin-Demeter_Internal_PN_Stream3_Intelligent_V2.640.0000000.5.R.1 |
| | 80921.zip |
| | General_SD-Yin-Demeter_Internal_NP_Stream3_Intelligent_V2.640.0000000. |
| | 5.R.180921.zip |
| | General_SD-Yin-Demeter_Internal_PN_Stream3_Intelligent_V2.640.0000000. |
| Software | 5.R.180921.zip |
| Package Info | PTZ firmware: |
| | General_PTZ818X-HNI-L8Q_MCU_V2.201.0000000.7.R.180823.zip |
| | General_PTZ818X-HNI-Q_MCU_V2.201.0000000.7.R.180823.zip |
| | General_SD65F8X-HNI_MCU_V2.201.0000000.7.R.180823.zip |
| | General_SD6A88X-HNI_MCU_V2.201.0000000.7.R.180823.zip |
| | General_SD6A88X-HNI-L_MCU_V2.201.0000000.7.R.180823.zip |
| | General_SD6A982-HNI_MCU_V2.201.0000000.7.R.180823.zip |
| ONIVIE Version | 46 42(\/2 4 2 540902) |
| ONVIF Version | 16.12(V2.4.2.549803) |
| WEB Version | 3.2.1.573922 |
| WEB Version | 6.2.1.676622 |
| | DH-SD6AL230F-HNI |
| | DH-SD6AL230F-HNI-IR |
| Applicable | DH-SD6AE230F-HNI |
| Models | DH-SD65F230F-HNI |
| | DH-PTZ12230F-IRB-N |
| | DH-PTZ12230F-LR8-N |

1

2 Newly Added or Enhanced Functions

| Function Name | Details |
|------------------------------------|--|
| | Test button is newly added on the interface, it can |
| GDPR | test the connection status between device and |
| | server. |
| | English, Spanish, French, Portuguese, German, |
| 14 languages | Italian, Polish, Russian, Persian, Korean, Czech, |
| | Arabic, Dutch, European Spanish |
| Overseas new NP baseline | For NTSC using |
| SD card snapshots and videos batch | |
| download | |
| Pixels counter function | |
| No-plugins solution | New version chrome, firefox, edge compatible |
| Lifelong status display changes | Only retain total working time, update times, last updating date |

$\bf 3$ Fix Bugs

| Fixed Bus | Details |
|--|---------|
| Onvif controls complex PTZ zoom in no effect | |
| PTZ action tips is not accuracy | |
| | |
| | |

4 Version Matched Info

| | NVR4416-16P-4KS2 | DH_NVR4XXX-4KS2_Chn_V3.216.0000000.0.R.180605.zip |
|--------|-------------------|---|
| NVR | NVR5832-16P-4KS2 | DH_NVR5XXX-4KS2_Chn_V3.216.0000000.0.R.20180530.zip |
| | DH-NVR608-32-4KS2 | DH_NVR6XX-4KS2_Chn_V3.210.0003.0.R.160714.BIN |
| NKB | NKB1000 | General_NKB1000_Eng_V2.620.0000000.0.R.20180115.zip |
| INCD | NKB5000 | DH_NKB5000_Eng_V3.210.0003.0.R.170930.BIN |
| Toolo | ConfigTool | General_ConfigTool_ChnEng_V4.09.0.R.20171010.zip |
| Tools | NetSDK | General_NetSDK_Eng_Win32_IS_V3.049.0000000.2.R.180127. 7z |
| DSS | DSS 70XXS2 | General_DSS70XXS2_Eng_Basic_Mysql_V3.10.001.R.2017111 0.tar |
| Client | SmartPSS | DH_SmartPSS_ChnEng_Win32_IS_V2.02.0.R.171124.zip |